



## Sinar AgriPro Moisture Analyser

- Extremely easy to use
- Rugged, portable design
- No sample preparation necessary
- Clear digital readout
- Averaging facility
- Calibrated for 19 crops
- Automatic temperature compensation
- Complete with carry case

### Product Description

The Sinar AgriPro is the ideal tool for checking the moisture of your cereals, pulses or oilseeds wherever you need to measure them. The AgriPro has been designed with portability in mind; its durable, compact construction means that it can always be by your side whenever you need it.

The Sinar AgriPro is extremely easy to use - simply pour the grain into the measurement cell, screw down the compression cap and read off the moisture content from the backlit digital display. The AgriPro measures the capacitance of the sample and automatically compensates for temperature. This simplicity does away with the need to mount your machine on a bench or weigh out precise quantities of samples, with the AgriPro accurate measurements can be taken in the middle of a field.

The AgriPro is an excellent tool as either the primary moisture meter for a budget conscious small farmer, or a mobile unit in conjunction with a larger bench mounted machine. Its versatility means that satisfaction is guaranteed.

### Product Features

### Supplier Address

Accuracy:	Better than +/-0.5% mc dependant upon application
Measurement range:	5% - 45% dependant upon application
Operating Environment:	0 - 45 °C
Dimensions:	21 x 7.5 x 7.5cm
Weight:	1.5Kg (including carry case)
Power Supply:	9v Alkaline
Principle of Operation:	Capacitance
Temperature Compensation:	Automatic
Readout resolution:	0.1% mc

Sinar Technology  
Unit 5, Camberley Business  
Centre  
Bracebridge  
Camberley  
Surrey  
GU15 3DP  
UK

**000 «Диаэм»**

Москва

ул. Магаданская, д. 7, к. 3 ■ тел./факс: (495) 745-0508 ■ sales@dia-m.ru

[www.dia-m.ru](http://www.dia-m.ru)

**С.-Петербург**  
+7 (812) 372-6040  
spb@dia-m.ru

**Новосибирск**  
+7 (383) 328-0048  
nsk@dia-m.ru

**Воронеж**  
+7 (473) 232-4412  
vrn@dia-m.ru

**Йошкар-Ола**  
+7 (927) 880-3676  
nba@dia-m.ru

**Красноярск**  
+7 (923) 303-0152  
krsk@dia-m.ru

**Казань**  
+7 (843) 210-2080  
kazan@dia-m.ru

**Ростов-на-Дону**  
+7 (863) 303-5500  
rnd@dia-m.ru

**Екатеринбург**  
+7 (912) 658-7606  
ekb@dia-m.ru

**Кемерово**  
+7 (923) 158-6753  
kemerovo@dia-m.ru

**Армения**  
+7 (094) 01-0173  
armenia@dia-m.ru

